

A.

EN

Before printing the Block Release template, ensure that your printer settings are set to 'actual size'.

NL

Controleer of je printerinstellingen staan ingesteld op 'ware grootte', voordat je deze Block Release afdruckt.

DE

Vergewissere dich, dass deine Drucker-einstellungen auf 'volle Größe' eingestellt sind, bevor du diesen Block Release druckst.

FR

Assurez-vous que les paramètres de votre imprimante sont réglés sur 'taille réelle' avant d'imprimer ce modèle de Block Release.

B.

EN

After printing, measure its length. If it's 12.5 cm, the Block Release is correctly scaled and ready for use. Now, move on to step 1, 2 and 3.

NL

Meet na het afdrukken de lengte. Meet deze 12,5 cm, dan is de Block Release op de juiste schaal afgedrukt en klaar voor gebruik. Volg nu stap 1, 2 en 3.

DE

Nach dem Drucken fängst du damit an, seine Länge zu messen. Wenn es 12,5 cm misst, ist der Block Release im richtigen Maßstab gedruckt und du kannst ihn jetzt verwenden. Folge nun Schritt 1, 2 und 3.

FR

Après l'impression, commencez par mesurer sa longueur. Si elle mesure 12,5 cm, alors le Block Release a été imprimé à l'échelle correcte et est maintenant prêt à être utilisé. Suis maintenant les étapes 1, 2 et 3.

lightswing®

Here it is, your Block Release!

1. Cut the Block Release out from this card
2. Remove the cover plates from the Lightswing® and place the Block Release on the base plate, with the logo against the bar
3. Check which cut out the screw fits into, and move the Lightswing® bar in the direction of the arrow.

Are you having trouble?
Don't worry, this is your lifeline!

+31 851 305 684
support@lightswing.eu

lightswing®
Block Release

12,5 cm

DUTCH DESIGN
by illumade®

Proudly produced by **illumade®**
Bright Ideas